


# Haier

HRB227W

HRB227S

**FRIDGE FREEZER**



USER'S INSTRUCTIONS

---

## General Safety Instructions

Read this manual thoroughly before first use, even if you are familiar with this type of product. We have provided many important safety statements in this manual concerning the use of this appliance. Always read and observe all safety statements. They reduce the risk of fire, electric shock and injury when correctly adhered to. Keep the manual in a safe place for future reference, along with the completed warranty card, purchase receipt and carton. If applicable, pass these instructions on to the next owner of the appliance.



Pay particular attention to safety messages that follow this safety alert symbol or the words DANGER, WARNING or CAUTION. These words are used to alert you to a potential hazard that can seriously injure you and others.

The instructions will tell you how to reduce the chance of injury and let you know what can happen if the instructions are not followed.

- DANGER** means that failure to read this safety statement may result in severe personal injury.
- WARNING** means that failure to read this safety statement may result in extensive product damage or serious personal injury.
- CAUTION** means that failure to read this safety statement may result in minor or moderate personal injury, property or equipment damage.



CAUTION:  
Flammable Gas

This symbol alerts you to take care as the appliance contains a flammable refrigerant. Do not expose it to high heat, sparks and open flames.

---

---


# CONTENTS

## General Safety Instructions

Parts and Features .....	2
Instructions for Installation .....	3
Cautions for Safety .....	4
Operation .....	4
Cleaning and Maintenance .....	6
Troubleshooting .....	7

- Please read this users operation manual before using.
- Because of production improvement, your refrigerator may vary from this user manual.

## Parts and Features




# Instructions for Installation


1. Do not tilt the refrigerator more than  $45^{\circ}$  from upright when moving it.

Do not apply force to any part such as the condenser, the door and its handle.


In order to prevent the refrigerator from deforming, or else its performance will be influenced.



2. Ensure that there is enough space around the refrigerator in order to let it work well .




3. The refrigerator should be kept away from high temperature, sunshine or humid conditions.




## Cautions for Safety

1. It must be checked that voltage used should be the same as the rated voltage before the refrigerator is used.
2. The power plug should have its own separated socket in order to prevent the electric wire from being over heated by other plugs.




3. Do not splash water on to the refrigerator. Otherwise it may cause malfunctions of the refrigerator or electric shock.
4. Do not store flammable materials such as petrol, LP gas and glue etc, in the refrigerator.



## Operation

1. When operating the refrigerator for the first time, set the thermostat dial at 3, connect to the electricity and run it without loading any food. Usually this takes 2 or 3 hours. Then set the thermostat dial to the desired setting and place foods into the refrigerator.

2. The temperature of the refrigerator can be adjusted by turning the thermostatic dial. Setting of the thermostat dial at 3~4 is the most suitable for general operation. The thermostat dial number higher the refrigeration capability stronger.
3. Do not put too much food in the refrigerator.  
Where possible open the door less often in order to maintain the temperature of the refrigerator and save electricity.




## Cautions


- Do not store bottled beverages in the freezer as liquids may expand during freezing causing the bottle to break and damage the appliance.
- If the power supply is turned off for any reason, wait ten minutes before starting the appliance again.

## Cleaning and Maintenance:

1. When cleaning the refrigerator, first disconnect the appliance from the power supply by removing the plug. Wipe the appliance carefully with a cloth and neutral cleaning agent, then wipe it clean with fresh water.




2. Never use acids, chemical solution, thinner, gasoline or the like to clean the refrigerator because they may damage the painting cover and plastic parts of it.



## Switching On Your Unit

1. Before connecting the unit to the mains supply, adjust the thermostat control dial to the desired position. Bear in mind that the higher the number, the lower the temperature. Position 3 is the recommended setting when operating at normal room temperature (between 16°C and 38°C). This is located on the right side of the cabinet. Connect the mains cable to the mains socket.
2. The unit may not operate at the correct temperature if it is in a particularly hot or a particularly cold room, or if you open the door often.
3. To ensure that the unit is cool enough to sufficiently chill your food, wait 24 hours before filling it with food.





## Troubleshooting

1. When the refrigerator does not operate :ensure that
  - The electric power is supplied and the voltage is normal.
  - The fuse is not burned out .
  - The power plug is plugged in firmly in the socket .
2. When the refrigerator is not cool enough: ensure that
  - The thermostat is at the correct setting .
  - There are enough space around the refrigerator .
  - The doors are not opened too frequently and for too long .
  - The refrigerator is not under direct sunlight or placed near the heat source .
  - There are not too many foods and hot foods in the refrigerator.
3. When the foods in the refrigerator are frozen: ensure that
  - The thermostat is at the correct setting .
  - There is not too much food in the refrigerator .
4. When the refrigerator operates too noisily : ensure that
  - The refrigerator is properly leveled .
  - The refrigerator is not touching objects around it .
  - The containers or solid packages stored inside are not touching each other .

## Note:

During periods of high humidity, moisture may form on the surfaces of the refrigerator. This is not a fault and maybe wiped away.

If after checking the above suggestions your refrigerator is still not functioning properly, please contact Customer Services without delay.

## Warnings

- \* This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- \* Children should be supervised to ensure that they do not play with the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- \* Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- \* Do not damage the refrigerant circuit
- \* Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

## IMPORTANT DISPOSAL INSTRUCTIONS



As a responsible retailer we care about the environment.

As such we urge you to follow the correct disposal procedure for your product and packaging materials. This will help conserve natural resources and ensure that it is recycled in a manner that protects health and the environment.

You must dispose of this product and its packaging according to local laws and regulations. Because this product contains electronic components and sometimes batteries, the product and its accessories must be disposed of separately from household waste when the product reaches its end of life. Contact your local authority to learn about disposal and recycling.

The product should be taken to your local collection point for recycling.

Same collection points accept free of charge.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.

## **R600a REFRIGERANT**

This appliance may contain a small quantity of environmentally friendly, but flammable , non-synthetic R600a refrigerant:

- Upon opening and installing your product, check that the tubing of the refrigerant circuit is not damaged during transportation.
  - Leaking refrigerant may cause eye injuries or ignite.
  - The room for installing appliance must be at least 1m<sup>3</sup> per 8g of refrigerant. The amount of refrigerant in the appliance can be found on the rating plate the back of the unit.
  - Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
  - Do not damage the refrigeration circuit.
- If you are unsure of the refrigerant type check the rating plate on the back of the unit.



技术要求：

1. 成品140\*210mm

2. 材质：封面封底105克铜版纸,内页70克双胶纸